



a Division
of
PROTEKSPECIALTY CO

Protek Specialty Co.

10315 Brighton Lane
Houston, TX 77031

email: sales@protekspecialty.com

P.O. Box 965
Stafford, TX 77497

Toll Free: (800) 610-8670
Main Office: (713) 667-6691
Fax: (713) 667-7867

website: www.protekspecialty.com

OIL

THIEF

Standard
Sliding-Valve OT



| PLASTIC BARRELS | FLUID OZ. |
|-----------------|-----------|
| OT12BP | 20.9 |
| OT16BP | 27.9 |
| OT18BP | 31.3 |
| OT24BP | 41.8 |
| OTIV12P | 18.4 |
| OTIV16P | 25.4 |
| OTIV18P | 28.8 |
| OTIV24P | 39.3 |



Internal Valve
Oil Thief (OTIV)

CALL TOLL FREE 800-610-8670



a Division
of
PROTEKSPECIALTY CO

Protek Specialty Co.

10315 Brighton Lane
Houston, TX 77031
email: sales@protekspecialty.com

P.O. Box 965
Stafford, TX 77497

Toll Free: (800) 610-8670
Main Office: (713) 667-6691
Fax: (713) 667-7867
website: www.protekspecialty.com

The **OIL THIEF** (OT, or OTIV for the Internal Valve unit), is a simple device that is utilized to collect accurate crude oil samples. Their lengths can be customized to suit your sampling needs. Sample cocks, also known as drain valves, can also be installed to test the different levels of your sample.

Features:

- Available in Slide Valve or Internal Valve.
- Standard barrel lengths are 12, 14, 16, 18, and 24 inches. (Custom barrel lengths are available upon request.)
- Barrels are available in plastic, Pyrex, or polished brass.
- Plastic and brass barrels can be installed with sample cocks upon request.
- Lowering devices available – your choice of either brass chain or braided rope with fittings.

Operation:

SNAP CLOSURE:

1. With the valve closed, make sure the trip rod is pushed fully into its sleeve, then lock the trip rod in this position by tightening the thumbscrew in the clutch top.
2. Slide Valve Thief: Open the valve by pulling it outward until the clutch pin holds it open.
Internal Valve Thief: Open the valve by pushing the lever down until the cock pin holds it open.
3. Put the bail assembly hook into the slot at the top of the trip rod sleeve.
4. Slowly lower the oil thief to the desired level in the tank.
5. Give the lowering line an abrupt upward jerk. This should trip the valve closed, making the sample ready for retrieval from the tank.

TANK BOTTOM BUMP CLOSURE:

1. Set the trip rod so its bottom end is at least 1/4 inch below bottom of oil thief, or extended to the desired sample height from bottom of tank.
2. Slide Valve Thief: Lock the trip rod securely in set position by tightening the thumbscrew in the clutch top.
Internal Valve Thief: Lock the trip rod securely in set position by tightening the thumbscrew in the valve cock.
3. Open the valve.
4. Lower the oil thief in a continuous motion until it bumps the tank bottom and trips the valve closed. Sample is now ready for retrieval.

Maintenance:

*All repairs must be sent back to factory for warranty to remain effective.

| PART# | | DESCRIPTION | PART# | |
|--------|--|----------------------|----------|---|
| OT | | OT & OTIV | OTIV | |
| O0001 |  | Body | O0001-IV |  |
| O0002 |  | Top Ring | O0002-IV |  |
| O0003 |  | Valve | O0003-IV |  |
| O0003A |  | O-Ring Valve Seal | O0003AIV |  |
| O0011A |  | Bail Assembly | O0011A |  |
| O0021 |  | Hanger | n/a | |
| M1012 |  | Cork Gasket (2 Req.) | M1012 |  |
| X0T09 |  | Brass Thumbscrew | X0T09 |  |
| X0T17 |  | Brass Acorn Nut | X0T29 |  |

| LOWERING DEVICES | |
|--------------------|-------------------------------|
| PART# | DESCRIPTION |
| O0025C w/ Fittings | 25' Brass Chain with Fittings |
| O0025R w/ Fittings | 25' Cotton Rope with Fittings |
| O0032C w/ Fittings | 32' Brass Chain with Fittings |
| O0032R w/ Fittings | 32' Cotton Rope with Fittings |

*Custom lengths of brass chain or braided rope available upon request.

CALL TOLL FREE 800-610-8670